



# E-CODER®)R900i™ Pit Installation

## Installation Guidelines

### **Required Tools:**

- 20 inch-pounds torque wrench
- Neptune magnet
- R900® RF test device



### **STEP 1**

Remove the dust cover from the F-connector on the coaxial cable. Place a small amount of Novagard gel from the included packet on the end of the connector.



### **STEP 2**

Secure the rubber washer to the MIU, applying some of the provided Novagard gel around the washer.



### **STEP 3**

Use a torque wrench to connect the coaxial cable to the F-connector on the E-CODER®)R900i™ register. **Tighten it to no less than 20 inch-pounds of torque.**



#### **STEP 4**

Fill the plastic connector housing with the rest of the provided Novagard gel and connect it to the latch plate by pressing and turning a quarter turn.



#### **STEP 5**

Slide the black compression nut down the cable and hand tighten it to the threaded portion of the connector housing.



#### **STEP 6**

Verify the activation using the RF test device or NGO™ app.

